







Nissin DIGITAL		Compatibility Chart																				Last update: Feb 2019				
Olympus Micro Four Thirds / Four Thirds Cameras																										
	E-M1 Mark II (OMD)	E-M1 (OMD)	E-M5 Mark II (OMD)	E-M5 (OMD)	E-M10 Mark III (OMD)	E-M10 Mark II (OMD)	E-M10 (OMD)	PEN-F	EP5	EP3	EP2	EP1	EP1.8 <b>New</b>	EP1.7	EP1.6	EP1.5	EP1.3	EP1.2	EP1.1	EP-M2	EP-M1	E-620	E-520	E-500	E-410	E-30
Nissin Model																										
Air 10s Commander (Four Thirds ver.)	●	●	●	●	●	—	●	—	●	●	●	●	●	—	●	●	—	●	●	●	●	—	—	—	—	—
Air 1 Commander (Four Thirds ver.)	●	●	●	●	○	●	●	±	●	●	●	●	●	—	●	●	●	●	●	●	●	●	●	●	●	●
D1700 A (Four Thirds ver.)	●	●	±	●	○	●	●	±	●	●	●	●	●	—	●	●	●	●	●	●	●	±	±	±	±	±
160A (Four Thirds ver.)	●	●	±	●	○	●	●	±	●	●	●	●	●	—	●	●	●	●	●	●	●	±	±	±	±	±
140 (Four Thirds ver.)	—	●	—	●	○	●	●	—	●	●	●	●	●	—	●	●	●	●	●	●	●	±	±	±	±	±
D1466 (Four Thirds ver.)	—	●	○	●	—	○	●	○	●	●	●	●	—	○	●	●	●	●	●	●	●	●	●	●	●	●

- Compatible Model
- Incompatible Model
- No information available. To be confirmed.

\*1 Unstable operation may appear when turn on the S-OVF Function ( Optical view finder simulation ) of EVF and shoot with EVF.  
 \*2 Flash's optical slave wireless mode is incompatible with camera's wireless flash system.  
 \*3 D1700A for FT version will be supporting Olympus E-M5 Mark II after flash firmware updated.

Nissin DIGITAL		Compatibility Chart																				Last update: Feb 2019				
Panasonic Micro Four Thirds Cameras *4																										
	GH5	GH4	GH3	GH2	GH1	GX8	GX7	GX7 Mark II / GX85 / GX80	GX1	G10	G9	G8 / G80 / G85	G7 / G70	G6	G5	G3	G2	G1	GF2	GF1	LX100	LX7	LX5	LX3	FZ200	
Nissin Model																										
Air 10s Commander (Four Thirds ver.)	—	—	●	—	●	—	—	—	—	—	—	—	—	●	—	—	●	●	●	●	—	●	●	●	●	
Air 1 Commander (Four Thirds ver.)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
D1700 A (Four Thirds ver.)	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
160A (Four Thirds ver.)	●	—	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
140 (Four Thirds ver.)	—	●	●	●	●	●	●	●	●	●	●	●	—	●	●	●	●	●	●	●	●	●	●	●	●	
D1466 (Four Thirds ver.)	—	●	●	●	●	○	●	○	●	●	—	—	○	●	●	●	●	●	●	●	●	●	●	●	●	

- Compatible Model
- Incompatible Model
- No information available. To be confirmed.

\*4 According to the specifications of Panasonic Lumix series, the continuous shooting function cannot be used when an external flash is installed on the hot shoe.



### Compatibility Chart

Last update: Feb 2019

Fujifilm Cameras																																
		GFX50s	X-H1	X-T3	X-T2	X-T1 / X-T1GS	X-T20	X-T10	X-Pro2	X-Pro1	X-E3	X-E2S	X-E2	X-E1	X-W1	X-A5	X-A3	X-A2	X-A1	X100F	X100T	X100S	X100	X70	X30	X20	X10	X-S1	HS50BKR	HS30BKR	HS20BKR	
Nissin Model																																
Air 10s Commander	—	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	—
Air 1 Commander	● *1 *2	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○
D1700 A	● *1 *2	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○
H60A	● *1 *2	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○
i40	● *1 *2	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●	○

- Compatible Model
- Incompatible Model

■ This camera supports HSS/FP High speed synchronize function.

\*1 The Fujifilm camera is supporting of High speed synchronize function after camera firmware updated

\*2 Flash can be insert on the hot shoe of main body or that of EVF. When inserted a flash on the EVF shoe, do not tilt-up EVF since this may make the EVF damage.